


Wiring the Nissan GTR Button



- Switch Terminals

1. Ground
2. N/A
3. N/A
4. MASTERCELL One-Button Start Input
5. N/A
6. N/A
7. Ground
8. Ignition Output from POWERCELL

